



The pipe installation recommended for product 30.1958, is to use either a Hunter Pan connector S227 or Mc Alpine's WC-CON1 pan connector. Then depending on your installation, one of the 'McAlpine Flexible Pan Connectors'; such as WC-F26P, WC-F18R, or WC-F26R.